Student Name: AMAL KRISHNA A B

BMS In Li-Ion Batteries

Assignment 1

Q1. What is a BMS? Types of BMS and differentiate the types of BMS.

A Battery Management System will manages the electronics of a rechargeable battery pack, thus becomes a crucial factor in ensuring electric vehicle safety. It safeguards both the user and the battery by ensuring that the cell operates within its safe operating parameters. BMS monitors the State of Health (SOH) of the battery, collects data, controls environmental factors that affect the cell, and balances them to ensure the same voltage across cells. A battery pack with a BMS connected to an external communication data transfer system or a data bus is referred to as a smart battery pack. It may include additional features and functions such as fuel gauge integration, smart bus communication protocols, General Purpose Input Output (GPIO) options, cell balancing, wireless charging, embedded battery chargers, and protection circuitry, all aimed at providing information about the battery's power status. This information can help the device conserve power intelligently. BMS will continuously monitor key parameters like voltage, current, internal resistance, and ambient temperature. The monitoring system in BMS will protect device by giving signal to generate alarm and to dis connect the load /charger. Every BMS is going to be use in different application so there is verity of BMS. A BMS may protect its battery by preventing it from operating outside its safe operating area, such as:[citation needed] Over-charging Over-discharging Over-current during charging Over-current during discharge Over-voltage during charging, especially important for lead-acid, Li-ion and LiFePO4 cells Under-voltage during discharging, especially important for Li-ion and LiFePO4 cells Over-temperature Charging while under low temperature Overpressure (NiMH batteries) Ground fault or leakage current detection (system monitoring that the high voltage battery is electrically disconnected from any conductive object touchable to use like vehicle body) The BMS may prevent operation outside the battery's safe operating area by: Including an internal switch (such as a relay or mosfet) which is opened if the battery is operated outside its safe operating area Requesting the devices to which the battery is connected to reduce or even stop using or charging the battery. Actively controlling the environment, such as through heaters, fans, air conditioning or liquid cooling

BMS is classified into 2 HARDWARE BMS and SOFTWARE BMS BMS. Mainly the functions are Over voltage cutoff Under voltage cutoff Continuous current Over current detection Over temperature cutoff

1.Hardware BMS: The BMS will also control the recharging of the battery by redirecting the recovered energy (i.e., from regenerative braking) back into the battery pack (typically composed of a number of battery modules, each composed of a number of cells). Battery thermal management systems can be either passive or active, and the cooling medium can either be air, liquid, or some form of phase change. Air cooling is advantageous in its simplicity. Such systems can be passive, relying only on the convection of the surrounding air, or active, using fans for airflow. Commercially, the Honda Insight and Toyota Prius both use active air cooling of their battery systems.[2] The major disadvantage of air cooling is its inefficiency. Large amounts of power must be used to operate the cooling mechanism, far more than active liquid cooling.[3] The additional components of the cooling mechanism also add weight to the

BMS, reducing the efficiency of batteries used for transportation. **2.Software BMS** It have all the features of hardware BMS. In addition to that they can control data, it have monitor to store data, transmit data via CAN, Bluetooth.A smart BMS offers benefits such as online monitoring for battery status regarding voltage, current, impedance, internal temperature, etc. 24/7 monitoring allows for timely response in case of potential battery accidents while reducing human maintenance costs. Furthermore, real-time alarming and online balancing enables the system to analyze uploaded data and auto-judge. For example, you can custom set the alarm threshold, and if the uploaded information is abnormal, the system sends out an alarm to maintenance via its server. A smart BMS can be called a BMS data center due to all the historical data collection, storage, and analysis. At the same time, you can get real-time battery information via a certain system. Additionally, it is straightforward to set up and operate due to the friendly user interface design of the smart BMS.Due to its numerous benefits, the smart BMS is applied as an assistant in various industries. To summarize, there are mainly six application areas with a wide array of use at various levels. These include:

- Data centers
- Power utility like substations
- Energy storage stations Financial institutions like banks.

Most of the battery monitoring suppliers normally provide common solutions for these industries. Therefore, DFUN provides a targeted solution for different industries that meet the needs of professional customers

different BMSCentralized BMS Architecture Has one central BMS in the battery pack assembly. All the battery packages are connected to the central BMS directly. The structure of a centralized BMS is shown in Figure 6. The centralized BMS has some advantages. It is more compact, and it tends to be the most economical since there is only one BMS. However, there are disadvantages of a centralized BMS. Since all the batteries are connected to the BMS directly, the BMS needs a lot of ports to connect with all the battery packages. This translates to lots of wires, cabling, connectors, etc. in large battery packs, which complicates both troubleshooting and maintenance.

Modular BMS Topology Similar to a centralized implementation, the BMS is divided into several duplicated modules, each with a dedicated bundle of wires and connections to an adjacent assigned portion of a battery stack. See Figure 7. In some cases, these BMS submodules may reside under a primary BMS module oversight whose function is to monitor the status of the submodules and communicate with peripheral equipment. Thanks to the duplicated modularity, troubleshooting and maintenance is easier, and extension to larger battery packs is straightforward. The downside is overall costs are slightly higher, and there may be duplicated unused functionality depending on the application

Primary/Subordinate BMS Conceptually similar to the modular topology, however, in this case, the slaves are more restricted to just relaying measurement information, and the master is dedicated to computation and control, as well as external communication. So, while like the modular types, the costs may be lower since the functionality of the slaves tends to be simpler, with likely less overhead and fewer unused feature

Distributed BMS Architecture Considerably different from the other topologies, where the electronic hardware and software are encapsulated in modules that interface to the cells via bundles of attached wiring. A distributed BMS incorporates all the electronic hardware on a control board placed directly on the cell or module that is being monitored. This alleviates the bulk of the cabling to a few sensor wires and communication wires between adjacent BMS modules. Consequently, each BMS is more self-contained, and handles computations and communications as required. However, despite this apparent simplicity, this integrated form does make troubleshooting and maintenance potentially problematic, as it resides deep inside a shield module assembly.

Q2 What are the technical parameters to keep in mind while procuring a BMS for assembling a battery pack?

Mainly, there are 6 components of battery management system.

- 1. Battery cell monitor
- 2. Cutoff FETs
- 3. Monitoring of Temperature.
- 4. Cell voltage balance
- 5. BMS Algorithms
- 6. Real-Time Clock (RTC)
- (b) Battery cell monitor A battery cell monitor primarily monitors the voltages for battery systems. It is a high-speed system that offers a low overall cost for high voltage measurements. The easiest way to determine the battery pack's charge is to monitor individual cell voltage with reference to the set voltage level. When the voltage of the first cell reaches the voltage limit, the charging automatically trips. It indicates that the battery charging limit has been reached. If the battery pack has a lesser charge than the average cell, then the least charged cell will reach the limit first, and the rest of the cells will be left partially charged.
- (b) Cutoff FETs FET driver is accountable for connection and isolation between load and charger of the battery pack. The behavior prediction is done through voltage, current measurements, and real-time detection circuitry. They can be connected to a battery pack's low or high side. NMOS FETs activation is needed for enabling high-side connection and requires a charge pump driver. A reference for the solid ground is set using a high-side driver for the rest of the circuitry. We use a low-side FET driver to reduce costs in integrated solutions since a charge pump is not needed. High voltage devices are not required in such cases. The ground connection of the battery pack floats using low-side cut-off FETs. This can affect the IC performance, making it more sensitive to insinuated noise measurement.
- (c) Monitoring of Temperature With the increase in product requirements, the batteries have been on a constant surge in delivering currents at fixed voltages. The continuous operation processes may cause a catastrophic event such as fire or explosion. We can identify whether battery charging or discharging is desirable using temperature measurements. Temperature sensors monitor the energy storage system or cell grouping for compact portable applications. The circuit temperature is monitored by the internal ADC voltage-powered thermistor. Employing the internal voltage reference helps reduce the temperature inaccuracies and improves the overall measurement system
- (d) Cell voltage balance It is crucial to determine the health of the battery pack. That is why cell voltage monitoring is done to ensure that the cells are in a proper running condition for attaining a long battery life. The operating voltage ranges from 2.5V to 4.2V in a lithium-ion battery. The battery life is significantly affected while performing battery operations beyond the voltage range. This reduces the life of a cell, which may even make it unfit for use. Connecting the battery pack in parallel increases the overall drive current, whereas series connection adds the overall voltage.
- (e) BMS Algorithms To make quick and effective decisions in real-time based on the information received. For this purpose, a microcontroller for battery management system is needed to col-

lect, organize and assess the information from the sensing circuitry. Rennes's' ISL94203 is the most famous example of employing a battery management system algorithm. It is a standalone digital solution embedded in a single chip with programmable capabilities. The memory space and microcontroller for battery management system clock cycles can be cleared using these standalone solutions

(f) Real-Time Clock Allowing the user to know the battery pack's behavior before any alarming event, the real-time clock acts as a black box system for time-stamping and memory storage. The BMS electronics is kept away from synchronizing with a third-party battery pack through battery authentication. The peripheral power circuitry is used around the components of battery management system through voltage reference/regulator.

Q3. What is the purpose of BMS with communication? What are the various protocols of communication used in a BMS?

The main goal of BMS is to keep the battery within the safety operation region in terms of voltage, current, and temperature during the charge, the discharge, and in certain cases at open circuit. When working with a BMS, you usually use a BMS IC. Depending on the BMS IC being used to control your BMS, you may need to connect to an external microcontroller or another external IC. These ICs need to be able to communicate with each other to send and/or receive information from one another. For example, you may have a BMS IC that doesn't have the capability of measuring current. Therefore, you use an external IC that measures current. This current data then needs to be fed to the BMS IC. Or, another example, is you have a microcontroller connected to the BMS IC that reads the data from the IC to make decisions governing the BMS. So communication protocols are vital for a battery management system with multiple ICs to be able to communicate with each other.

1.UART

UART, which stands for Universal Asynchronous Receiver/Transmitter, is the most widely used communication protocol used in battery management systems. UART is a form of serial communication, which means bits are sent one after another sequentially instead of multiple bits sent at once which is what occurs with parallel communication. The UART communication is widely used for communication between a microcontroller and the BMS IC in a BMS. It is also used for communication between the microcontroller and the GSM, bluetooth, or WIFI modules. It is also used extensively for debugging purposes when developing the firmware of a BMS to check particular sections or lines of code; using UART, the output of code can be printed and displayed on a screen. In UART communication, two UARTs communicate directly with each other UARTs transmit data asynchronously, which means there is no clock signal to synchronize the output of bits from the transmitting UART to the sampling of bits by the receiving UART. UARTs do not operate on clock signals but with baud rates. The baud rate is the speed of data transfer expressed in the number of bits per second that the communication occurs in. The baud rates must be set equally on the transmitting and receiving ends in order for communication to work. The baud rates can only vary by about 10% before the timing of the bits goes too far off. Only 2 wires are needed to transmit data between 2 UART devices. For example, if we have 2 devices, device 1 and device 2, each device has 2 connections, Rx and Tx. The Tx of each device connects to the Rx of the other device. This way the transmitting data of one device goes to the receiving end of the other device, thus, establishing communication.

2.CAN

CAN, Controller Area Network, is the most widely used communication protocol in the automotive industry. CAN communication are used frequently in automotive applications because it removes all signal noises such as electromagnetic noises. It also removes a host of wire harnesses from a system. It is one of the most robust and reliable communication protocols. CAN applications can be used in simple to extremely complex applications. They are used in both gasoline and electric vehicles. The CAN protocol is used with a chip that allows for CAN communication. Texas Instruments is one manufacturer which makes CAN chips that allow for CAN communication between devices. One example of this is the TCAN1042-Q1 Automotive Fault Protected CAN Transceiver with CAN FD.

The microcontroller connects to the CAN chip, which then connects to the outside devices. The CAN chip has TXD and RXD pins, which allow it to communicate with the microcontroller. The TXD pin is for the transmission of data and the RXD pin is for the receiving of data. So these are the most common and most used communication protocols for battery management systems.

3.SPI

SPI, Serial Peripheral Interface, is a master-slave type protocol that provides a simple and low cost interface between a microcontroller and its peripherals. The SPI protocol uses a dedicated clock signal that is created by the master device to synchronize the transmitter and receiver or Master and Slave. One device is considered the Master of the bus (usually a microcontroller) and all the other devices (peripheral ICs or even other microcontrollers) are considered as slave devices. The microcontroller can communicate with the BMS IC via SPI communication, along with other peripheral devices that can communicate with SPI communication. These applications ome; ide memory devices such as SD cards, MMC, EEPROM, or Flash, sensors such as tmeperature or pressure sensors, control devices such as ADC, DAC, digital POTs, and audio codec, and other devices such as touch screen devices, LCD devcies, RTC, or video game controllers. SPI communication uses 4 lines for each device. There is an input data line (receiving data), and output data line (transmitting data), a clock line, and a chip select line to identify which slave device the master is trying to communicate with. If there are multiple SPI slave devices connected to the master, then the chip select line functions to select the specific slave device either to transmit data to it or receive data from it..

12C

SPI, Serial Peripheral Interface, is a master-slave type protocol that provides a simple and low cost interface between a microcontroller and its peripherals. The SPI protocol uses a dedicated clock signal that is created by the master device to synchronize the transmitter and receiver or Master and Slave. One device is considered the Master of the bus (usually a microcontroller) and all the other devices (peripheral ICs or even other microcontrollers) are considered as slave devices. The microcontroller can communicate with the BMS IC via SPI communication, along with other peripheral devices that can communicate with SPI communication. These applications ome; ide memory devices such as SD cards, MMC, EEPROM, or Flash, sensors such as tmeperature or pressure sensors, control devices such as ADC, DAC, digital POTs, and audio codec, and other devices such as touch screen devices, LCD devices, RTC, or video game controllers.SPI communication uses 4 lines for each device. There is an input data line (receiving data), and output data line (transmitting data), a clock line, and a chip select line to identify which slave device the master is trying to communicate with. If there are multiple SPI slave devices connected to the master, then the chip select line functions to select the specific slave device either to transmit data to it or receive data from it. Specifically, the pins of a SPI bus are MOSI (Master Out, Slave In), MISO (Master In, Slave Out), SCLK (Serial clock), and CS or SS (Chip Select or Slave Select). The MOSI is how the master device transmit data to the slave and the MISO is how the master device reads information from a slave device. SPI communication is a full-duplex communication that occurs with very high speeds. By full duplex, it is meant that the transmission and receiving of data can occur simultaneously. This is advantageous over UART or I2C communication, in which there can only be transmission or receiving of data that can occur at a given time but not both simultaneously. The disadvantage of SPI is that 4 wires are required instead of 2 for UART and I2C.